

MITCHELL ALUMINIUM SCREEN DOORS

DO IT YOURSELF MEASURE FORM

HOW TO MEASURE YOUR DOOR WAY
 APPROACH YOUR DOOR LOOKING FROM THE OUTSIDE
 THERE SHOULD BE A DESIGNATED REBATE TO WHERE
 YOUR NEW DOOR WILL BE PLACED. (LOOK AT ILLUSTRATION)
 YOU WILL BE REQUIRED TO MEASURE AT 8 SEPERATE POINTS

NAME:

CONTACT:

DESIGN:

COLOUR:.....

DEDUCT 8 MILLEMETRES AWAY FROM HEIGHT

CUSTOMER SIGNATURE:.....

DEDUCT 7 MILLEMETRES AWAY FROM WIDTH

ORDER NUMBER:.....

1. LEFT SIDE-BOTTOM OF SILL TO TOP OF INTERNAL REBATE AS MEASURED – 8mm -----mm
2. RIGHT SIDE-BOTTOM OF SILL TO TOP OF INTERNAL REBATE AS MEASURED – 8mm -----mm
3. LEFT BOTTOM TO RIGHT BOTTOM OF INTERNAL REBATE AS MEASURED – 7mm -----mm
4. LEFT MIDDLE TO RIGHT MIDDLE OF INTERNAL REBATE AS MEASURED – 7mm -----mm
5. LEFT TOP TO RIGHT TOP OF INTERNAL REBATE AS MEASURED – 7mm -----mm
6. LEFT BOTTOM TO TOP RIGHT OF INTERNAL REBATE - ACTUAL SIZE -----mm
7. RIGHT BOTTOM TO LEFT TOP OF INTERNAL REBATE - ACTUAL SIZE -----mm
8. (HANDLE HEIGHT)----BOTTOM OF SILL TO TOP OF EXISTING DOOR KNOB IF SECURITY LOCK HAS TO BE HIGHER, OR BOTTOM OF DOOR KNOB IF SECURITY LOCK HAS TO BE LOWER -----mm

(PLEASE TICK HANDLE SIDE)

